



INSTALLATION SHEET

Any damaged or missing parts?
Parts will be shipped to you directly.
info@eagletruckaccessories.com

TOOLS REQUIRED: Safety Glasses, Drill, 1/2" Drill Bit, Tape Measure

STEP 1: Place the bed slide into the truck box and push the slide forward until the bed slide is against the front of the truck box. Will require a minimum of 2-people.

STEP 2: Center the bed slide between the wheel wells in the truck box, making sure that it is still tight to the front of the box once centered.

STEP 3: Lift the handle and pull the slide out to the first locking position, exposing the steel frame underneath the bed slide. Notice the wide portion of the frame rail resting on the floor of the truck box.

STEP 4: Drill a 1 1/2" hole in the middle of the rail on each side as close to the front of the box as you can. Checking underneath the vehicle **BEFORE** drilling to make sure there are no obstructions in the way. (i.e. wiring harness, cross ribs, etc.) The holes drilled at the front should not be more than 10" from the front of the truck box.

STEP 5: With two front holes drilled, use 1/2" hardware to bolt down the front of the bed slide and tighten at this time.

STEP 6: With the front of the slide mounted and tight, pull the handle on the bed slide and pull to its last locking position to expose the steel frame.

STEP 7: Drill a 1 1/2" hole on each side as far back from the front as you can in the middle of the steel frame, again, checking under the vehicle for any obstructions.

STEP 8: With both holes drilled at the rear of the frame, use 1/2" hardware and bolt down the rear of the bed slide and tighten at this time.

STEP 9: Install is complete. Please enjoy your new Eagle Bed Slide.

Feel like sharing your install?

Send a photo of your bed slide to info@eagletruckaccessories.com, so that we can share it with our Eagle Family on Instagram and Facebook.